


# THE PHANTOM™



Item #	Part#	Description	Item #	Part#	Description	Item #	Part#	Description
2	9009	Direct Feed Breech	21A	9049	Nylon Set Screw 10-32x1/8"	40	9039	Puncture Seal
3	9006	11" Screw-in Barrel	22	9048	Bolt Assembly (TPC)	41	9806	O-ring, 14x2
	9007	8" Screw-in Barrel	23	9068	Adjusting Rod, Hex 1/4"	42	9415	Puncture Adapter Assm
	9008	14" Screw-in Barrel	24	9200	Pump	43	9805	O-ring, 14x2
4	9069	Hex to Slot, Adapter	25	9212	Bolt Rod with Nut	44	9414	10 Round Extension Tube
5	9420	Valve / Air Adapter	26	9311	8-32 Thumbscrew, Front		9015	15 Round Extension Tube
9	9036	Valve Spring	27	9300	Frame Assembly	45	9024	Ball Retainer
10	9112	Cup	28	9306	Lock Washer, 1/4"	46	9458	Vertical Adapter Screw"
11	9111	Seal	29	9307	Grip Screw, 1/4-20x3/4"	47	9424	Vertical Adapter
12	9113	Eyelet	30	9304	Grip Cover	48	9434	Compression Elbow
13	9110	Cup Seal Assembly	31	9305	Grip	49	9435	Metal Tube
14	9046	O-ring, #12	32	9316	10-32 Thumbscrew, Rear	50	9417	Valve / Hose Air Adapter
15	9115	Retainer	33	9029	Feed Port Cover	51	9206	Nylon Washer
16	9103	Power Tube	34	9070	Adjusting Rod (TPC)	52	9205	Return Spring
17	9116	Power Tube Assm	35	9003	Breech, Top Feeding	53	3045	45 Grip Frame
18	9062	Anti-Kink Hammer Assm	36	9011	Horizontal Feed	54	9441	Sleeve
19	9051	Main Spring	37	9013	Screw 8-32x5/8" SHCS	55	9442	Compression Nut
20	9052	Tuned Port Compensator	38	9410	Stock Housing			
21	9045	Bolt (21A, 14)	39	9038	Puncture Pin Assembly			